

Thermal Strains

Effect of temperature:


two folks → properties = $f(T)$ ← negligible for "normal" ΔT
→ strain produced (w or w/o stress)

$$\epsilon_T = \frac{\Delta l}{l_0}$$

$$\Delta T = T_t - T_r$$

where T_t is Temp. at anytime t .

T_r is the reference temp.



α = linear coefficient of thermal expansion
(mm/mm °C or in/in °F)

$$\epsilon_T = \alpha \Delta T \quad \left[\Rightarrow \sigma_T = \epsilon_T L = \alpha \Delta T L \right]$$

$$\epsilon_{total} = \epsilon_{mechanical} + \epsilon_{thermal}$$

↓ ↓
loads temp.