

## Intrinsic & Extrinsic Semiconductors

- Intrinsic Semiconductor : A pure Semiconductor material with no impurity atoms and no lattice defects in the crystal.


In other words:

$$\begin{aligned} \text{Free electron concentration} &= \text{hole concentration} &= \text{intrinsic electron} \\ n \text{ (electron / cm}^3\text{)} &= p \text{ (hole / cm}^3\text{)} &= n_i \end{aligned}$$

- $n_i$  depends only on the type of Semiconductor & temperature  
e.g  $n_i$  for Si at 300 K  $\approx 1.4 \times 10^{10} \text{ cm}^{-3}$

- As  $T \uparrow \rightarrow n_i \uparrow$  ( the higher the temperature the more  $n_i$  )
- Intrinsic semiconductors have extremely large Resistivity.

- $R = \rho \frac{L}{A_{\text{cross section}}} = \rho \frac{L}{w \times t}$  ,  $\rho$ : resistivity ( $\Omega \cdot \text{cm}$ )



- $\rho = \frac{1}{\sigma_n + \sigma_p}$        $\sigma_n$ : electron conductivity  
    $\sigma_p$ : hole conductivity

$$\sigma_n = q \times n \times \mu_n \quad \mu_n: \text{electron mobility} = \frac{V_e}{E} \rightarrow \text{we can find current}$$

$$\sigma_p = q \times p \times \mu_p \quad \mu_p \text{ hole mobility}$$

$$\uparrow T \rightarrow \downarrow \mu \quad (\text{as temperature goes up, mobility decreases})$$

$$\uparrow \text{ Impurity concentration} \rightarrow \downarrow \mu \quad (\text{as impurity concentration goes up, mobility decreases})$$


Ex1: for pure Si, assuming electron mobility  $\mu_e = 1000 \text{ cm}^2/\text{s.V}$  :

$$\rho = \frac{1}{\sigma_n + \sigma_p} \quad \sigma_n = 1.6 \times 10^{-19} \times 1.4 \times 10^{10} \times 1000 = 2.44 \times 10^{-6}$$

$$\sigma_p = 1.22 \times 10^{-6}$$

$$\rightarrow \rho = \frac{1}{3 \times 1.22 \times 10^{-6}} = 273 \text{ k } \Omega \cdot \text{cm}$$

So for a typical transistor-sized piece of Si:



all units in ( $\mu\text{m}$ )

$$R = 273 \times 10^3 \times \frac{0.2 \times 10^{-4}}{0.1 \times 10^{-4} \times 5 \times 10^{-4}} = 109 \times 10^7 = 1.09 \text{ G}\Omega$$

## Impurities

- impurities are added to intrinsic Semiconductors to increase  $n$  or  $p \rightarrow$  we get extrinsic Semiconductors
- 2 types of impurities :
  1. Donors:  $n \uparrow$  such as P & As ( Group 5 )
    - one electron will be donated and becomes free
  2. Acceptors:  $p \uparrow$  such as B & Ar ( Group 3 ) – they accept an electron and create a hole
- mass action law :  $n p = \text{constant} = n_i^2$ 
  - $n \uparrow \rightarrow p \downarrow$  by the same factor
- Donors become +ve charges , Acceptors become -ve charges. However, Semiconductor remain neutral ( charge conservation )
  - total +ve charges = total -ve charges
  - $p + N_D = n + N_A$
  - if  $n > p \rightarrow n$  type semiconductor
  - if  $p > n \rightarrow p$  type semiconductor

Ex2: for the same piece of Si in Ex1. If Donors are added at concentration of  $10^{16} \text{ cm}^{-3}$ .  
How much will the Resistance be?

Sol:

$$N_D = 10^{16} \text{ cm}^{-3}$$

$$n \cdot p = n_i^2 = 10^{20}$$

$$p + N_D = n + N_A$$

$$p + 10^{16} = n$$

$$p = \frac{10^{20}}{n} \rightarrow \frac{10^{20}}{n} + 10^{16} = n \quad * \text{ solve by iteration (let } n = 10^{10} \text{ -the min- )}$$

$$\frac{10^{20}}{10^{10}} + 10^{16} = n = 10^{10} + 10^{16} \approx 10^{16}$$

Substitute the new value in \*

$$\frac{10^{20}}{10^{16}} + 10^{16} = n = 10^4 + 10^{16} \approx 10^{16}$$

$$\therefore n = 10^{16} \text{ cm}^{-3}$$

Conclusion  $n \approx N_D - N_A$   $p = \frac{10^{20}}{10^{16}} = 10^4 \text{ cm}^{-3}$

Hence, again  $\mu_e = 1000 \text{ cm}^2/\text{s.V}$  :

$$\rho = \frac{1}{\sigma_n + \sigma_p} = \frac{1}{1.6 \times 10^{-19} \times 10^{16} \times 1000} \approx 0.6 \Omega \cdot \text{cm}$$

$$R = 0.6 \frac{0.2}{0.1 \times 0.5 \times 10^{-4}} = 2.4 \text{ k}\Omega$$