


Compound Stresses

Forces which cause normal stresses: F_x, M_y, M_z

Forces which cause shearing stresses: $F_y, F_z, M_x(T)$

Linear elastic behavior is assumed. \Rightarrow

Superposition principle can be utilized to compute the compound stresses.



- normal
- shear

Normal Stress:

$$\begin{aligned}\sigma_x &= \sigma_{x_1} + \sigma_{x_2} + \sigma_{x_3} \\ &= \underset{\oplus}{\frac{F_x}{A}} - \underset{\oplus}{\frac{M_z y}{I_z}} + \underset{\oplus}{\frac{M_y z}{I_y}}\end{aligned}$$

← scalar

Be careful about signs \oplus !

Shearing Stress:

$$\vec{\tau} = \vec{\tau}_{xy} + \vec{\tau}_{xz} + \vec{\tau}_{xs}$$

\downarrow \downarrow \downarrow
 V_y V_z $M_x(T)$

← vector

$$\tau_{xy} = \frac{V_y Q_z}{I_z b_z} ; \tau_{xz} = \frac{V_z Q_y}{I_y b_y} ; \tau_{xs} = \frac{T r}{J}$$

\downarrow
for circular section
it depends on section