

**King Fahd University of
Petroleum & Minerals
Computer Engineering Dept**

**COE 341 – Data and Computer
Communications**

Term 082

Dr. Ashraf S. Hasan Mahmoud

Rm 22-148

Ext. 1724

Email: ashraf@kfupm.edu.sa

6/2/2009

Dr. Ashraf S. Hasan Mahmoud

1

Lecture Contents

1. Frequency-Division Multiplexing
2. Synchronous Time-Division Multiplexing
3. Statistical Time-Division Multiplexing
4. DSL/ADSL Technology


6/2/2009

Dr. Ashraf S. Hasan Mahmoud

2

What is MULTIPLEXING?

- A generic term used where more than one application or connection share the capacity of one link
- Why?
 - To achieve better utilization of resources




6/2/2009

Dr. Ashraf S. Hasan Mahmoud


3

Frequency-Division Multiplexing - Transmitter

- $m_i(t)$: analog or digital information
- Modulated with subcarrier $f_i \rightarrow s_i(t)$
- $m_b(t)$ composite baseband modulating signal
- $m_b(t)$ modulated by $f_c \rightarrow$ The overall FDM signal $s(t)$



(a) Transmitter




6/2/2009

Dr. Ashraf S. Hasan Mahmoud


Spectrum function of composite baseband modulating signal $m_b(t)$

Frequency-Division Multiplexing - Receiver

- $m_b(t)$ is retrieved by demodulating the FDM signal $s(t)$ using carrier f_c
- $m_b(t)$ is passed through a parallel bank of bandpass filters – centered around f_i
- The output of the i^{th} filter is the i^{th} signal $s_i(t)$
- $m_i(t)$ is retrieved by demodulating $s_i(t)$ using subcarrier f_i



Frequency-Division Multiplexing - Example 1: Cable TV



Frequency-Division Multiplexing – Example 1: Cable TV – cont'd

- Cable has BW \sim 500 MHz \rightarrow 10s of TV channels can be carried *simultaneously* using FDM
- Table 8.1: Cable Television Channel Frequency Allocation (partial): 61 channels occupying bandwidth up to 450 MHz

Channel No	Band (MHz)	Channel No	Band (MHz)	Channel No	Band (MHz)
2	54-60	22	168-174	42	330-336
3	60-66	23	216-222	43	336-342
4	66-72	24	222-234	44	342-348
5	76-82
6	82-88				
7	174-180				
8	180-186				
9	186-192				
10	192-198				
11	198-204				
12	204-210				
13	210-216				
FM	88-108				
14	120-126				
15	126-132				
16	...				
...	...				




6/2/2009

Dr. Ashraf S. Hasan Mahmoud

7

Frequency-Division Multiplexing – Example 2: Voiceband Signals

- $m_1(t)$: voiceband signal – bandwidth = 4000 Hz
- When modulated by a carrier $f_1 = 64$ KHz \rightarrow two identical sidebands; overall bandwidth = 2×4 KHz = 8 KHz
- Information of $m_1(t)$ is preserved if one of the sidebands is eliminated (filtered out) \rightarrow bandwidth of modulated signal = 4 KHz
- (c) shows spectrum for composite signal using three subcarriers



6/2/2009

Dr. Ashraf S. Hasan Mahmoud

8

Frequency-Division Multiplexing – Example 2: Voiceband Signals (2)


- Animation of FDM concept for voice calls

6/2/2009

Dr. Ashraf S. Hasan Mahmoud

9

Frequency-Division Multiplexing – Analog Carrier Systems




WCB/McGraw-Hill


© The McGraw-Hill Companies, Inc., 1998

Synchronous Time-Division Multiplexing - Transmitter

- Digital sources $m_i(t)$ – usually buffered
- A scanner samples sources in a cyclic manner to form a frame
- $m_c(t)$ is the TDM stream or frame → frame structure is fixed
- Frame $m_c(t)$ is then transmitted using a modem → resulting analog signal is $s(t)$



(a) Transmitter



(b) TDM Frames


6/2/2009

Dr. Ashraf S. Hasan Mahmoud

11

Synchronous Time-Division Multiplexing - Receiver

- TDM signal $s(t)$ is demodulated → result is TDM digital frame $m_c(t)$
- $m_c(t)$ is then scanned into n parallel buffers;
- The i^{th} buffer correspond to the original $m_i(t)$ digital information



6/2/2009

Dr. Ashraf S. Hasan Mahmoud

12

Synchronous Time-Division Multiplexing

- Animation of Synchronous TDM concept

6/2/2009

Dr. Ashraf S. Hasan Mahmoud

13

Synchronous Time-Division Multiplexing – Bit/Character Interleaving

- TDM frame: sequence of slots – fixed structure – NOTE: no header/error control for this frame
 - One or more slots per digital source
 - The order of the slots dictated by the scanner control
 - The slot length equals the transmitter buffer length:
 - Bit: bit interleaving
 - Used for synchronous sources – but can be used for asynchronous sources
 - Character: character-interleaving
 - Used for asynchronous sources
 - Start/stop bits removed at tx-er and re-inserted at rx-er
- Synchronous TDM: time slots are pre-assigned to sources and FIXED
 - If there is data, the slot is occupied
 - If there is no data, the slot is left unoccupied

This is a cause of inefficiency!

6/2/2009

Dr. Ashraf S. Hasan Mahmoud

14

TDM Link Control

- TDM frame:
 - No header and no error detection/control – these are per connection procedures
 - Frame synchronization is required – to identify beginning and end of frame
 - Added-digit framing: One control bit is added to each start of frame – all these bits from consecutive frame form an identifiable pattern (e.g. 1010101...)
 - These added bits for framing are inserted by system → control channel
 - Frame search mode: Rx-er parses incoming stream until it recognizes the pattern → then TDM frame is known
- Pulse stuffing:
 - Different sources may have separate/different clocks
 - Source rates may not be related by a simple rational number
 - Solution: inflate lower source rates by inserting extra dummy bits or pulses to match the locally generated clock speed


6/2/2009

Dr. Ashraf S. Hasan Mahmoud

15

TDM – Example 1

- Step1: convert analog sources to digital using PCM
 - The **sampling theorem** determines the no of samples/sec
- The analog sources produce 16 sample/sec altogether → 64 kb/s when converted to digital
- Note pulse stuffing is used to raise the 7.2 kb/s rate to 8 kb/s (a rational fraction of 64 kb/s) for digital sources




6/2/2009

Dr. Ashraf S. Hasan Mahmoud

16

TDM – Example2: Digital Carrier Systems

- Voice call is PCM coded \rightarrow 8 b/sample
- DS-0: PCM digitized voice call – $R = 64$ Kb/s
- Group 24 digitized voice calls into one frame as shown in figure \rightarrow DS-1: 24 DS-0s
- Note channel 1 has a digitized sample from 1st call; channel 2 has a digitized sample from 2nd calls; etc.



Notes:

1. The first bit is a framing bit, used for synchronization.
2. Voice channels:
 - 8-bit PCM used on five of six frames.
 - 7-bit PCM used on every sixth frame; bit 8 of each channel is a signaling bit.
3. Data channels:
 - Channel 24 is used for signaling only in some schemes.
 - Bits 1-7 used for 56 kbps service
 - Bits 2-7 used for 9.6, 4.8, and 2.4 kbps service.

Figure 8.9 DS-1 Transmission Format


6/2/2009

Dr. Ashraf S. Hasan Mahmoud

17

Figure 8-28

T-1 Frame




6/2/2009

Dr. Ashraf S. Hasan Mahmoud

© The McGraw-Hill Companies, Inc., 1998

TDM – Example2: Digital Carrier Systems (2)

- TDM



6/2/2009

Dr. Ashraf S. Hasan Mahmoud

19

Example: Problem 8-8

- 8-8: In the DS-1 format, what is the control signal data rate for each voice channel?

Solution:

There is one control bit per channel per six frames. Each frame lasts 125 μ sec. Thus:

$$\text{Data Rate} = 1 / (6 \times 125 \times 10^{-6}) = 1.33 \text{ kbps}$$


6/2/2009

Dr. Ashraf S. Hasan Mahmoud

20

Statistical Time-Division Multiplexing

- Dynamic and on-demand allocation of time slots



6/2/2009

Dr. Ashraf S. Hasan Mahmoud

21

Statistical Time-Division Multiplexing Frame Format

- Clearly, the aim of statistical TDM is increase efficiency by not sending empty slots
- But it requires overhead info to work:
 - Address field
 - Length field



(a) Overall frame



(b) Subframe with one source per frame



(c) Subframe with multiple sources per frame


6/2/2009

Dr. Ashraf S. Hasan Mahmoud

22


Statistical Time-Division Multiplexing – Modeling

- Data items (bits, bytes, etc) are generated at any time – source may be intermittent (bursty) not constant
- R b/s is the peak rate for single source
 - αR b/s is the average rate for single source ($0 \leq \alpha \leq 1$)
- The *effective* multiplexing line rate is M b/s
- Each data item requires T_s sec to be served or tx-ed
- Data items may accumulate in buffer before server is able to transmit them \rightarrow Queuing delay



Statistical Time-Division Multiplexing - Performance

- Let I – number of sources
- R – data rate for each source
- M – effective capacity of multiplexed line
- α – mean fraction of time each source is transmitting
- $K = M/(IR)$ – ratio of multiplexed line capacity total maximum input



Statistical Time-Division Multiplexing – Performance (2)

- **Notes:**

- **K** is a measure of compression achieved on the multiplexed line
- $\alpha < K < 1$:
 - $K = 1$ for synchronous TDM
 - If $K < \alpha$ (or $\rho > 1$) \rightarrow input is greater the line capacity (NOT STABLE)
- ρ is measure of the load: for example, if $M = 50\text{kb/s}$ and $r = 0.25$, then system load is $\rho M = 12.5 \text{ kb/s}$

- **Queueing Model Perspective:**

λ : average number of arrivals per time unit

T_s : average time to serve an arrival

ρ : traffic intensity = λT_s

Aggregate input (load or λ) = αIR
 Capacity (service) = $M = 1/T_s$
 Traffic Intensity, $\rho = \lambda T_s = \lambda/M$
 $= \alpha IR/M$
 $= \alpha/K$
 For stable system $0 \leq \rho < 1$

6/2/2009

Dr. Ashraf S. Hasan Mahmoud

25

Statistical Time-Division Multiplexing – Performance (3)

- (Refer to Queueing Model [slide](#))
- Mean number of items in system (waiting & being served), **N** is given by:

$$N = \frac{\rho^2}{2(1-\rho)} + \rho$$

- Mean residence time (waiting and service), **T_r** is equal to

$$T_r = N / \lambda$$

6/2/2009

Dr. Ashraf S. Hasan Mahmoud

26

Statistical TDM – Performance – Example

- 5 terminals are statistically multiplexed on 38.4 kb/s modem line; Each of the terminals transmits at a rate $R = 9.6$ kb/s 25% of the time. For each transmitted 5 bytes of user data (the data item), the asynchronous TDM frame contains 1 byte for address field and 1 byte for length field.
- a) What is the average number of data items in the system?
b) How many terminals we can connect to this system before the average delay exceeds 100 msec?

6/2/2009

Dr. Ashraf S. Hasan Mahmoud

27

Statistical TDM – Performance – Example - Solution

- a) $I = 5$ terminals; $R = 9.6$ kb/s; $\alpha = 0.25$;
 $M = 38.4$ kb/s – note for every 5 bytes of data the link transmits 7 bytes \rightarrow Effective $M = (5/7) * 38.4 = 27.4$ kb/s

$$\lambda = \alpha IR = 12 \text{ kb/s, and } \rho = \lambda/M = 0.4374$$

$$N = \rho^2 / (2(1-\rho)) + \rho = 0.6076 \text{ data item}$$

$$T_r = N/\lambda = 0.051 \text{ second}$$

- b) What is maximum I such that $T_r \leq 0.1$ sec
using the above values for R , α , and Effective M and allowing I to vary from 5, 6, .., 11*

$$\text{For } I = 8, T_r = 0.079 \text{ sec}$$

$$\text{For } I = 9, T_r = 0.104 \text{ sec}$$

Therefore the maximum no of terminal to connect without making T_r exceed 100 msec is $I = 8$

*note that 11 is the maximum possible value for I regardless of T_r – this is because ρ should always remain ≤ 1 , but $\rho = \alpha IR/M \leq 1$; which means $I \leq M/(\alpha R) = 11.4$; therefore the maximum number of terminals without consideration for T_r can be 11

Statistical Time-Division Multiplexing

- Animation of Asynchronous TDM concept

Example: Problem 8-13

- **8-13: Ten 9.6 kb/s lines are to be multiplexed using TDM. Ignoring overhead bits, what is the total capacity required for synchronous TDM? Assuming that we wish to limit the average multiplexed line utilization to 0.8, and assuming that each line is busy 50% of the time, what is the capacity required for statistical TDM?**

Example: Problem 8-13 - solution

Synchronous TDM: $M = IR$;
 $R = 9.6\text{kb/s}$, $I = 10 \rightarrow M = ?$
 $M = 9600 \text{ bps} \times 10 = 96 \text{ kbps}$

Statistical TDM:

Remember that $\rho = \alpha IR/M$;
 $\rho = 0.8$, $\alpha = 0.5$, $R = 9.6\text{kb/s}$, $I = 10 \rightarrow M = ?$
 $M = 9600 \text{ bps} \times 10 \times 0.5/0.8 = 60 \text{ kbps}$

6/2/2009

Dr. Ashraf S. Hasan Mahmoud

31

Asymmetric Digital Subscriber Line (ADSL)

- **References:**
 - **Chapter 8 – section 4**
 - **http://whatis.techtarget.com/definition/0,289893,sid9_qci213915,00.html#dslsumry**
 - **DSL forum at:**
http://www.dslforum.org/about_dsl.htm?page=aboutdsl/tech_info.html

6/2/2009

Dr. Ashraf S. Hasan Mahmoud

32

Digital Subscriber Line (DSL) Technology


- Provides access to wide area public digital network – or the internet
- Uses the existing telephone wire at home
 - The wire originally deployed to carry voice (up to 4 kHz) signal
 - The wire has a bandwidth \sim MHz or more depending on distance
- DSL modem – a modem that provides high-speed digital transmission over ordinary telephone wire
- xDSL: refers to the different flavors of the DSL technology: ADSL, HDSL, VDSL, and RADSL

6/2/2009

Dr. Ashraf S. Hasan Mahmoud

33

Digital Subscriber Line (DSL) Technology - Evolution



Digital Subscriber Line (DSL) Technology

- **Connects home/small businesses to the central office**
- **Provides up to 8.448 Mb/s on downlink – motion video (on demand) is possible**
- **Typical ADSL bit rates:**
 - Downlink 512 kb/s ~ 1.544 Mb/s
 - Uplink 128 kb/s

6/2/2009

Dr. Ashraf S. Hasan Mahmoud

35

Asymmetric Digital Subscriber Line (ADSL) – cont'd


- **Asymmetric bit rate provided on downlink (from central office to subscriber) is greater than bit rate provided on uplink (from subscriber to central office)**
 - **Matches our use of the internet – more downloads compared to uploads**
- **ADSL uses FDM or Echo Canceling on the telephone wire**

6/2/2009

Dr. Ashraf S. Hasan Mahmoud

36

ADSL Equipment




From: http://www.dslforum.org/about_dsl.htm?page=aboutdsl/tech_info.html

37

ADSL Modem Structure

DSLAM: Digital Subscriber Line Access Multiplexer




From: http://www.dslforum.org/about_dsl.htm?page=aboutdsl/tech_info.html

38

ADSL and FDM

- Lower range 0-4 kHz – voice
- Data uses **25 kHz and up**
 - Uplink: 25 to ~200 kHz
 - Downlink: ~250 to 1000 kHz
- FDM is used to multiplex voice, uplink, and downlink signals



- FDM is used within the uplink band and downlink bands to multiplex multiple bit streams
- Echo cancellation: in this case the uplink and downlink bands overlap – logic at both ends is required to separate the two signals (variable uplink bandwidth – avoiding using the higher bandwidth of the wire)

6/2/2009

Dr. Ashraf S. Hasan Mahmoud

39

Comparison of xDSL Alternatives

	ADSL	HDSL	SDSL	VDSL
Data rate	1.5 to 9 Mbps downstream 16 to 640 kbps upstream	1.544 or 2.048 Mbps	1.544 or 2.048 Mbps	13 to 52 Mbps downstream 1.5 to 2.3 Mbps upstream
Mode	Asymmetric	Symmetric	Symmetric	Asymmetric
Copper Pairs	1	2	1	1
Range (24-gauge UTP)	3.7 to 5.5 km	3.7 km	3.0 km	1.4 km
Signaling	Analog	Digital	Digital	Analog
Line Code	CAP/DMT	2B1Q	2B1Q	DMT
Frequency	1 to 5 MHz	196 kHz	196 kHz	≥ 10 MHz
Bits/cycle	Varies	4	4	Varies

UTP = unshielded twisted pair

HDSL:

- Alternative for T1
- Distance ~ 3.7 km
- Two twisted-pair lines
- Target: Businesses

SDSL:

- HDSL version for residential
- Uses single twisted pair
- Uses Echo cancellation

6/2/2009

Dr. Ashraf S. Hasan Mahmoud

40

Discrete Multitone – 4 kHz Subchannels


- The modulation technique used for ADSL
- The available transmission bandwidth (upstream or downstream) is divided into 4-kHz subchannels
 - Each has its own subcarrier or TONE (therefore the name multitone!)
- A combination of QAM and FDM

6/2/2009

Dr. Ashraf S. Hasan Mahmoud

41

Bandwidth Division in ADSL



Channel 0 – voice
 Channels: 1-5 - idle
 Channels: 6-30 (25 channels) – upstream data
 Channels: 31-255 (225 channels) – 224 downstream data + 1 control

6/2/2009


Dr. Ashraf S. Hasan Mahmoud

42

Discrete Multitone - Subchannels

Maximum theoretical download speed (if all wire bandwidth of 1.104kHz = 1104/4.3 = 256 channels is/are utilized) = 60 X 256 = 15.36 Mb/s
Practical = 1.5 to 9 Mb/s depending on line distance and quality

- Total usable bandwidth is divided into 4 kHz subchannels
- Each channel can send up to 60 kb/s
- During modem initialization – modem sends test signals on each of these subchannels




- i^{th} Subchannel is assigned a rate equal to $\alpha_i \times 60 \text{ kb/s}$ where $0 \leq \alpha_i \leq 1$

6/2/2009

Dr. Ashraf S. Hasan Mahmoud

43

Discrete Multitone Transmitter



44

DSLAM (Digital Subscriber Line Access Multiplexer)

- **DSLAMs sit in a carrier's central office between a subscriber line and the subscriber's service-provider network. They separate voice and DSL traffic and then control and route DSL traffic between the subscriber and the service provider.**

Problems of INTEREST

- Problem List: 8-9, 8-10, 8-11, 8-12, 8-13, and 8-17
- Example on slide 25